

HOTELSKO UREDSKI SEF

PL-1938M 3050-2S

! Molimo vas da ne držite rezervne ključeve u sefu!

Značajke

- Čvrsta čelična konstrukcija nudi izvrsnu zaštitu od provala. Zaključavanje s dva snažna zasuna promjera 20 mm.
- Praktičan motorizirani sustav zaključavanja s najnovijom tehnologijom.
- Lako čitljiv, veliki LED zaslon prikazuje status sefa.
- Otvaranje pomoću 4-6-znamenkastog koda ili rezervnog ključa, uključena su dva rezervna ključa.

NAPAJANJE

Baterije

- Radni napon proizvoda su 4 AA baterije.
- Sustav automatski prelazi u stanje male potrošnje energije.

UPOZORENJE: Prilikom zamjene baterija, zamijenite sve baterije odjednom i nikada ne koristite stare i nove baterije zajedno. Ne miješajte navedene baterije s drugim vrstama baterija.

OTVARANJE VRATA

- Unesite osobni kod ili glavni kod, vrata će se otvoriti.

ZATVARANJE VRATA

- Unesite osobni kod i pritisnite "#", vrata će se zatvoriti.

POSTAVLJANJE OSOBNOG KODA

- Unesite tvornički zadani kod 1 2 3 4, LCD zaslon će prikazati "open" (otvoreno).
- S otvorenim vratima unesite četveroznamenkasti kod.
- Pritisnite "#", zaslon prikazuje "CLOSED" (zatvoreno), što znači da su vrata zatvorena.
- Zaslon će prikazati uneseni kod, što znači da je vaš novi kod prihvaćen i možete otvoriti vrata svojim novim kodom.

POSTAVLJANJE GLAVNOG KODA

- Pritisnite "***" dok su vrata otvorena, zaslon prikazuje "PROG".
- Nakon što "PROG" nestane, unesite unaprijed postavljeni glavni kod (izvorni glavni kod hotelskog načina je "011223") i zaslon prikazuje "- NEW -".
- Nakon što "NEW" nestane, unesite svoj novi kod (6 znamenki) unutar 5 sekundi, zaslon će prikazati "AGAIN".
- Nakon što "AGAIN" nestane, ponovno unesite svoj novi kod (6 znamenki) unutar 5 sekundi, zatim zaslon prikazuje "DONE", što znači da je postavljanje novog glavnog koda uspješno. Ako nije, zaslon će prikazati "ERROR".

SIGURNOSNE FUNKCIJE:

• SAKRIVANJE KODA

Pritisnite "*" prije unosa koda, tada zaslon neće prikazivati broj niti će prikazivati uneseni kod nakon zatvaranja vrata.

• AUTOMATSKO ZAKLJUČAVANJE

Nakon četiri uzastopna pogrešna unosa koda, sustav će se automatski zaključati. Tijekom tog vremena, zaslon će prikazivati "HOLD15" pri svakom pritisku tipke. Nakon 15 minuta, sustav će ponovno omogućiti unos. (Vrijeme možete postaviti od 0 do 60 minuta putem programskog upravljačkog položaja.)

OTVARANJE SEFA U HITNIM SITUACIJAMA

Ako dođe do kvara elektroničkog sklopa, niske razine baterije ili nepoznatih kodova, koristite rezervni ključ za otvaranje vrata.

KORIŠTENJE REZERVNOG KLJUČA ZA OTVARANJE VRATA

- Uklonite poklopac za rezervni ključ.
- Umetnite rezervni ključ i okrenite u smjeru suprotnom od kazaljke na satu kako biste otvorili vrata.

POGREŠKE I NJIHOVA ZNAČENJA

Kada zaslon prikazuje sljedeće poruke, to znači da postoje pogreške. Postupite prema sljedećim uputama.

- ERROR — kod je netočan, potrebno je unijeti ispravan kod.
- ERROR1 — vrata se ne mogu normalno otvoriti, zasun je blokiran. Lagano pritisnite vrata kako biste otpustili zasun.
- ERROR2 — kada je zasun blokiran (vjerojatno su vrata ostala otključana), nije moguće zaključati vrata. Lagano pritisnite vrata kako biste dovršili zaključavanje.

POGREŠKE I NJIHOVA ZNAČENJA

Učvrstite sef na mjesto koje nije lako pomaknuti.

- Izbušite rupe za tiple (ili vijke za stezanje) na odgovarajućem mjestu.
- Okrenite tiple suprotno od kazaljke na satu kako biste ih odvojili.
- Upotrijebite tiple (ili vijke za stezanje) kako biste pričvrstili sef na zid.
- Provjerite je li sef pravilno postavljen i zatim zategnite sve vijke.

HOTEL OFFICE SAFE

PL-1938M 3050-2S

! Please do not keep emergency keys in your safe!

Features:

- Heavy duty steel construction offers excellent burglary protection. Locked by two strong bolts with $\phi 20\text{mm}$
- Convenient motorized locking system, incorporating the latest technology.
- Easy to read, large LED display let's you know the status of the safe.
- Open by 4-6 digital code or emergency key, two override keys included

POWER SUPPLY

Battery

- The working voltage for the product is equal to 4 AA batteries.
- System will turn into micro power consuming state automatically.

CAUTION: When replacing batteries, do replace all the batteries at once and never use old and fresh batteries together. Never mix the specified batteries with other types of batteries in use.

OPEN THE DOOR

- Enter the personal code or master code, the door will open

CLOSE THE DOOR

- Enter the personal code and press “#”, the door will close.

SETTING THE PERSONAL CODE

- Enter the factory default code 1 2 3 4 the LCD display will indicate “open”.
- With door opened, enter four-digit code
- Press “#”, screen displays “CLOSED”, which means the door is closed.
- The screen will show the code entered, which means your new code has been accepted and you could open the door by your new code showed.

SETTING THE MASTER CODE

- Press “*” when the door is open, the display reads “PROG”.
- After “PROG” disappears, enter preset master code (The original master code of hotel mode is “011223”) and reading “- NEW -”.
- After “NEW” disappears, input your new code (6 digits) within 5 seconds, the display will read “AGAIN”.
- After “AGAIN” disappears, input your new code (6 digits) again within 5 seconds, then the display reads “DONE”, which means the new master code setting is successful, if not, the display will reads “ERROR”.

SECURITY FUNCTION:

• HIDE THE CODE

Press “*” before enter code, then the display will not show your the number and also will not show back the code you entered when the door closed.

• AUTOMATICAL LOCK

After four consecutive times of error codes, the system will be locked out automatically. During that time, the display will display “HOLD15” every press. 15 minutes later, the system will start again, allowing button entry. (You can set up for 0 to 60 minutes through the programming controlling position.)

OPENING THE SAFE IN EMERGENCY

Once the electronic circuit malfunctioned, or battery is low, or codes unknown, please use emergency key to open the door.

Use the emergency key to open the door

- Remove the emergency key cover.
- Insert the emergency key and turn anticlockwise to open the door.

ERROR INDICATION

When screen displays the following indications, it means there are errors. Please operate according to the following instructions.

- ERROR——means the code is incorrect, and you need to enter correct code.
- ERROR1——means the door can not be open normally, and the bolt is blocked. Please push the door slightly to loosen the bolt.
- ERROR2—— when the bolt is blocked (probably the door is left unlatched), there is no way to lock the door. Please push the door slightly to finish locking.

MOUNTING METHOD

Fix the safe in the place which is not easy to move.

- Drill holes for expansion bolts (or clamping screws) in the right place.
- Turn the expansion bolts counter clockwise to separate.
- Use the expansion bolts (or clamping screws) to secure the case to the wall.
- Make sure the case is mounted in place as required and then tighten all screws.